

# 330 DS / 750 DS Counter Flashing Installation Instructions Appendix

For 330 DS / 750 DS Self-Flashings

Parts List	Quantity
1 Counter Flashing	(1)

Additional Materials and Tools	Quantity
1 Membrane Flashing Boot (Not Provided)	1
2 Hose Clamp (Not Provided)	1
3 Silicone Sealant (Not Provided)	-

**Note:**

These installation instructions are intended to provide basic installation practices for attaching and installing a Membrane Flashing Boot. Solatube International Inc. does not provide these materials and should be sourced by others. Please follow all manufacturers recommendations for proper installation and water proofing methods.

**1** Place Membrane Flashing Boot over Self-Flashing

Membrane Flashing Boot

Hot Air Gun

**2** Apply Hose Clamp to top edge of Membrane Flashing Boot

Hose Clamp

Install Hose Clamp no closer than 1/2 inch from top edge of flashing to ensure proper fit of Counter Flashing

Securely Fasten Hose Clamp and Apply Silicone to Seal Top Edge

**3** Install Counter Flashing

Counter Flashing

Return to main set of instructions (P/N: 950160) to complete installation.