



**SOLATUBE®**  
Innovation in Daylighting.

# Solatube® SolaMaster® Series


Solatube® 330 DS Daylighting System \*\*

Solatube® 750 DS Daylighting System \*\*

## Installation Instructions

### Open Ceiling

For Closed Ceiling, see back of this page.



Parts List *		Quantity
1	Outer Dome Options	
	a. 750 DS Dome with Raybender® 3000 Technology	(1)
	b. 330 DS Dome with LightTracker™ Reflector	(1)
2	Inner Dome Option	(1)
	a. Inner Dome for 750 DS (Optional)	(1)
	b. Inner Dome for 750 DS (Optional, Polycarbonate**)	(1)
3	Dome Fasteners	
	a. Dome Screw #8 X 1 5/8 in (40 mm)	(4)
	b. Dome Spacer	(3)
	c. Dome Seal	(1)
4	Tube Ring	(1)
	a. Tube Ring Seal (Required for all Open Ceiling Units)	(1)
5	Roof Flashing (4 in (100 mm)***, 8 in (200 mm)***, 11 in (280 mm)*** or Curb Cap))	(1)
	a. Flashing Screws - #10 X 2 in (50 mm)	(21)
6	Spectralight® Infinity Tubes	
	a. 24 in (610 mm) Extension Tube with Tube Fastener Kit	(1)
	b. 48 in (1220 mm) Extension Tube with Tube Fastener Kit	(1)
7	Tube Fastener Kit	(1)
	a. Tube Screws - #8 X 9/16 in (14 mm)	(5)
	b. 2 in (50 mm) Foil Tape - 18 ft (5.5 m)	(1)
8	Diffuser for Open Ceiling	(1)
	a. Diffuser Seal	(1)

#### Required Tools:

Saber or Reciprocating Saw	Utility Knife
Flat Bar	Caulking Gun
Tape Measure	Lumber Crayon
Screw Gun with Phillips Head	Metal Shears
Magnetic Compass	Required Safety Equipment
Hammer	Drill Bit #40 (3/32 in/2.5 mm)

\*Components shown not included in all kits, see label on box.

\*\*Required for High Velocity Hurricane Zone (HVHZ) areas.

\*\*\* Some of these products are




and meet criteria for  
UFC 4-010-01 DoD Minimum Antiterrorism Standards for Buildings. See  
warning section for approved configurations.

For the most current Installation Instructions, please visit [www.solatube.com/instructions](http://www.solatube.com/instructions)

Solatube International, Inc. | 2210 Oak Ridge Way | Vista, CA 92081-8341 | [www.solatube.com](http://www.solatube.com) | T: 888.SOLATUBE

# Closed Ceiling



Parts List *		Quantity
1	Outer Dome Options	
	a. 750 DS Dome with Raybender® 3000 Technology	(1)
	b. 330 DS Dome with LightTracker™ Reflector	(1)
2	Inner Dome Option	(1)
	a. Inner Dome for 750 DS	(1)
	b. Inner Dome For 750 DS (Optional, Polycarbonate***)	(1)
3	Dome Fasteners	
	a. Dome Screw #8 X 1 5/8 in (40 mm)	(4)
	b. Dome Spacer	(3)
	c. Dome Seal	(1)
4	Tube Ring	(1)
	a. Tube Ring Seal **	(1)
5	Roof Flashing (4 in (100 mm)**†, 8 in (200 mm)**†, 11 in (280 mm)**† or Curb Cap)	(1)
	a. Flashing Screws - #10 X 2 in (50 mm)	(21)
6	Spectralight® Infinity Tubes	
	a. Top Tube with Angle Adapter	(1)
	b. Bottom Tube with Angle Adapter	(1)
7	Tube Fastener Kit	(1)
	a. Tube Screws - #8 X 9/16 in (14 mm)	(10)
	b. 2 in (50 mm) Foil Tape - 18 ft (5.5 m)	(2)
8	Spectralight® Infinity Tubes	
	a. 24 in (610 mm) Extension Tube (optional) with Tube Fastener Kit	(1)
	b. 48 in (1220 mm) Extension Tube (optional) with Tube Fastener Kit	(1)
9	Transition Box (Plastic/Polymeric) or (Metal with Softlight Technology)	(1)
	a. Natural Effect Lens (Optional)	(1)
	b. Transition Box Hold Down Clip	(4)
	c. Drill Tip Screw - #6 X 1 5/8 in (40 mm) (For Hard Ceiling Application Only)	(4)
	d. Drill Tip Screw - #8 X 5/8 in (16 mm)	(2)
10	Diffuser	(1)

\*Components shown not included in all kits, see label on box.

\*\*†Required for High Velocity Hurricane Zone (HVHZ) areas.

\*\*\* Some of these products are




and meet criteria for  
UFC 4-010-01 DoD Minimum Antiterrorism Standards for Buildings. See  
warning section for approved configurations.

For the most current Installation Instructions, please visit [www.solatube.com/instructions](http://www.solatube.com/instructions)

Solatube International, Inc. | 2210 Oak Ridge Way | Vista, CA 92081-8341 | [www.solatube.com](http://www.solatube.com) | T: 888.SOLATUBE


# Closed Round Ceiling



Parts List *		Quantity
1	Outer Dome Options	
	a. 750 DS Dome with Raybender® 3000 Technology	(1)
2	b. 330 DS Dome with LightTracker™ Reflector	(1)
	Inner Dome Option	(1)
3	a. Inner Dome for 750 DS	(1)
	b. Inner Dome For 750 DS (Optional, Polycarbonate**)	(1)
4	Dome Fasteners	
	a. Dome Screw #8 X 1 5/8 in (40 mm)	(4)
	b. Dome Spacer	(3)
5	c. Dome Seal	(1)
	Tube Ring	(1)
6	a. Tube Ring Seal **	(1)
	Roof Flashing (4 in (100 mm)**†, 8 in (200 mm)**†, 11 in (280 mm)**† or Curb Cap))	(1)
7	a. Flashing Screws - #10 X 2 in (50 mm)	(21)
	Spectralight® Infinity Tubes	
8	a. Top Tube with Angle Adapter	(1)
	b. Bottom Tube with Angle Adapter	(1)
9	Tube Fastener Kit	(1)
	a. Tube Screws - #8 X 9/16 in (14 mm)	(10)
10	b. 2 in (50 mm) Foil Tape - 18 ft (5.5 m)	(2)
	Spectralight® Infinity Tubes	
11	a. 24 in (610 mm) Extension Tube (optional) with Tube Fastener Kit	(1)
	b. 48 in (1220 mm) Extension Tube (optional) with Tube Fastener Kit	(1)
12	Round Closed Ceiling Housing	(1)
	a. Tube Ring Seal	(1)
	b. Rivet	(6)
	c. Screw #8 x 2 1/2" (63 mm)	(6)
	d. Screw Hex Head - #8 x 5/8" (16 mm)	(6)
	e. Screw Hex Head - #8 x 2" (50 mm)	(6)
13	f. Screw - #8 X 9/16 in (14 mm)	(1)
	Natural Effect Lens	(1)
14	Spectralight® Infinity Reflective Sleeve	(1)
	Mounting Plate (Hard Ceiling or Suspended Ceiling)	(1)
15	Diffuser	(1)
	a. Diffuser Torsion Spring	(3)
16	b. Diffuser Spring Lock	(3)

\*Components shown not included in all kits, see label on box.

\*\*†Required for High Velocity Hurricane Zone (HVHZ) areas.

\*\*†† Some of these products are  and meet criteria for

UFC 4-010-01 DoD Minimum Antiterrorism Standards for Buildings. See warning section for approved configurations.

For the most current Installation Instructions, please visit [www.solatube.com/installations](http://www.solatube.com/installations)

Solatube International, Inc. | 2210 Oak Ridge Way | Vista, CA 92081-8341 | [www.solatube.com](http://www.solatube.com) | T: 888.SOLATUBE

## Table of Contents:

<u>Section</u>	<u>Page</u>
Warnings.....	4-5
Curb Cap.....	6
Closed Ceiling.....	6-11
Closed Round Ceiling.....	11-17
Open Ceiling.....	18-19
Curb Cap Insulation.....	20
Self-Flashing.....	21-22
DSA Requirements.....	22
Turret Extension .....	23
0-90 Degree Angle Adaptor.....	23
Dome Edge Protection Band.....	24
Hard Ceiling.....	25
Suspension Wire Kit.....	26-27
Natural Effect Lens.....	28-29
Thermal Insulation Panel (TIP).....	30-32
Closed Ceiling TIP with Daylight Dimmer.....	33-34
Notes.....	35



## WARNING



**Do not proceed with the installation until you have read the entire instructions, including these warnings. Use of materials or methods not authorized by Solatube International will result in an invalid warranty.**

Solatube International, Inc. (seller) assumes no responsibility or obligation whatsoever for the failure of an architect, contractor, installer, or building owner to comply with all applicable laws, ordinances, building codes, electrical codes, energy codes, fire and safety codes and requirements, roof warranties and adequate safety precautions. Installation of this product should be attempted only by individuals skilled in the use of the tools and equipment necessary for installation. Protect yourself and all persons and property during installation. If you have any doubt concerning your competence or expertise, consult a qualified expert before proceeding.



### **Install at your own risk!**

Solatube product installations may be dangerous and include the potential for death, personal injury and property damage. The hazardous conditions include but are not limited to the following:

- During installation, the Solatube Daylighting System's reflective tubes may focus sunlight, causing intense heat or fire. Remove protective film only after the parts have been installed. Prior to and during installation, do not leave tubes in contact with combustible materials or unattended, especially near direct sunlight. Avoid skin burns.
- Do not leave debris from installation process unattended. Scrap from tubing and foil tape are highly reflective and if left unattended can focus sunlight and can cause intense heat or fire. Clean up all unused material and trash and store or discard in proper covered locations.
- Solatube Daylighting System and Solar Star products may have sharp edges. Always wear leather or canvas gloves while handling and installing products.
- Solatube product installations require climbing and working at dangerous heights, including on ladders, scaffolding, roofs and in attic spaces. Risk of death, personal injury and property damage may result from a fall, or from falling objects. Use extreme caution to minimize risk of accidental injury, including, but not limited to the following procedures:
  - Clear area below your work space of all people, animals and other items.
  - Avoid working on surfaces that are slippery or wet.
  - Use foot-wear with excellent traction.
  - Use only strong, well supported ladders.
  - Work only in calm dry weather.
  - When in the attic, ensure that your weight is supported at all times with structurally sound framing; drywall material is not designed to carry a person's weight.

For the most current Installation Instructions, please visit [www.solatube.com/instructions](http://www.solatube.com/instructions)



- To reduce the risk of fire, electric shock, and personal injury, basic safety precautions should always be followed when using electric tools, including always wearing safety goggles or other suitable eye protection, and ensuring work area is clear of all electrical wires, gas pipes, water pipes, and other obstacles.
- When working in the attic or other dusty areas, use of a mask or respirator is recommended to avoid lung irritation. Attic spaces may be dark, confined, and subject to extreme temperatures. Beware of sharp protruding objects. Do not attempt installation without having someone within range of your voice or close enough to come to your aid if necessary.
- Solatube products are not designed to withstand the weight of a person, tools or other objects. Walking or placing objects on the system could cause personal injury and property damage. If the product is damaged, the structural capacity may be weakened; therefore the system should be repaired immediately. For safe installation and use, do not deviate from these installation instructions.
- Additional support is recommended for long vertical and all horizontal tube runs. Review local building requirements and consult with appropriate building code official for proper material and placement of additional support. Avoid galvanic reaction (corrosion) if dissimilar metals are used.

### Electrical Components

- Before installing, servicing, or cleaning unit, switch power off at service panel and lock service panel to prevent power from becoming switched on accidentally. When the service disconnecting means cannot be locked, securely fasten a prominent warning device such as a tag to the service panel.

### Re-Roofing

- Solatube products require special care if removed for re-roofing. In order to ensure proper removal and re-installation, please contact your Solatube International representative.

Please refer to the installation tips for the appropriate product below:



### Daylighting Systems Installation Tips

These instructions are a step-by-step guide for the installation of a Solatube Daylighting System in the following conditions. For other roof types, please contact your Solatube International representative for additional information.

**Built Up Flat Roof - Single Ply/Membrane - Asphalt Shingle - Low/No Pitched - Pitched -  
Prefabricated Curbs - Metal Roof Panels**



### Daylighting Systems Installation Tips (Continued)

- Allow at least 2-3 hours for the installation, particularly if this is your first installation.
- During the day, turn off all the lights in the room to see how much natural light comes in through the windows, and determine the best position for the Solatube Daylighting System. To light a specific area, place the system over the area, not in the center of the room. This will prevent the desired area from being shaded by tall objects in the room.
- Measure the distance between the roof and the ceiling. If you don't have enough tubing, contact your Solatube International representative for additional tubing.
- Avoid roof locations shaded by trees, ridges and chimneys, or near water channels or valleys. Also avoid roof areas with obstructions such as fire sprinklers, HVAC equipment, gas, water or drain pipes, air ducts or flues and make sure that the roof is adequate to endure an installation without damaging its waterproofing properties or weakening the building structure.
- All adhesives, seals and tapes are recommended to be applied to a clean and dry surface at a minimum of 70°F (21°C) for maximum performance.
- Foil tape contains a pressure sensitive adhesive and pressure must be applied at all seams for proper bonding. Foil tape is not intended for use as structural support of the extension tubes. For structural integrity use manufacturer supplied fasteners on all overlapping extension tube joints.
- Uninstalled product that is stored and exposed to excessive heat and or humidity can experience damage. Store product prior to installation in a cool dry place.
- For installations where high levels of suit or debris may be present it may be necessary to use foil tape to seal the diffuser to the tubing to prevent the excess debris from entering the tubing.
- FM (Factory Mutual): The 750 DS Dual Dome with Polycarbonate Inner Dome and the 330 DS with Polycarbonate Dome, when used with the Dome Edge Protection Band, meet requirements for FM Approvals.



- UFC-4-010-01: All SolaMaster assemblies meet requirements for United Facilities Criteria (UFC) DoD minimum antiterrorism standard for buildings.



### Daylight Dimmer Installation Tips

- Install Solatube Daylight Dimmer only on a properly aligned Solatube Daylighting System.
- Use only UL recognized components approved for this listing.

For the most current Installation Instructions, please visit [www.solatube.com/instructions](http://www.solatube.com/instructions)

Solatube International, Inc. | 2210 Oak Ridge Way | Vista, CA 92081-8341 | [www.solatube.com](http://www.solatube.com) | T: 888.SOLATUBE

# Curb Cap Installation Instructions

1

Install Curb Cap

a

b

c

d

\*For HVHZ apply 4 more screws to curb cap.

Go to Page 18 for Open Ceiling instructions.

## Closed Ceiling Installation Instructions

2

Set Transition Box  
For plastic polymeric or metal transition box.

a

b


c

For DSA (Division of the State Architect) project, please see additional fastening requirements in accessories section on page 22.

3


### Install Top and Bottom Tube Angle Adapters; Measure Tube Run

Tube ring can be installed on Top Tube with Angle Adapter or an Extension tube (see step 5).



### Note: For use with Metal Transition Box



Install Spectralight Softlight Tubing at bottom of tube run for best results.  
Use no more than one (1) Softlight Extension Tube for each assembly.



4

## Option 1: Assemble 24 in (610 mm) Extension Tube



Use notches to create tapered tube.

**Note:** Spectralight Softlight Extension Tubes must be assembled to be parallel not tapered.

4


## Option 2: Assemble 48 in (1220 mm) Extension Tube

Use slots to create tapered tube.

**Note:** Spectralight Softlight Extension Tubes must be assembled to be parallel not tapered.

5


## Assemble and Install Tube Run

For the most current Installation Instructions, please visit [www.solatube.com/instruction](http://www.solatube.com/instruction)




## Alternative Tube Run

For curb heights or obstructing structural members that require an Extension Tube as the Top Tube, use configuration below:




## 6

### Connect Tube Run and Fasten to Transition Box






## 7a

### Install diffuser (Plastic Transition Box Only)




For the most current Installation Instructions, please visit [www.solatube.com/instructions](http://www.solatube.com/instructions)  
Solatube International, Inc. | 2210 Oak Ridge Way | Vista, CA 92081-8341 | [www.solatube.com](http://www.solatube.com) | T: 888.SOLATUBE







9

## Option 2: Install 750 DS Dome




Insert Dome spacer short end first from inside dome.





9

## Option 3: Install 750 DS Outer Dome with Inner Dome\*




Insert Dome spacer long end first leaving every other hole open.




\*Polycarbonate inner dome required for HVHZ areas; dip screw threads in sealant.

## Round Closed Ceiling Installation Instructions

10

Assemble Round Housing  
Align pre-punched holes and install rivets.

Align Fastening Holes



For the most current Installation Instructions, please visit [www.solatube.com/instructions](http://www.solatube.com/instructions)  
Solatube International, Inc. | 2210 Oak Ridge Way | Vista, CA 92081-8341 | [www.solatube.com](http://www.solatube.com) | T: 888.SOLATUBE

# Hard Ceiling New Construction Installation Instructions (No ceiling in place)

11

Install Hard Ceiling Mounting Plate to Ceiling Framing  
Wood or metal framing

Adjust mounting plate to framing width.

Screw #8 x 2.5

Fasten mounting plate to framing.

12

Bend Fastening Tabs Up

13

Cut Ceiling Opening  
Use a saw or rotary cut out tool after the hard lid has been installed.

14

### Install Round Housing





Push housing into opening until bottom is flush with ceiling.

Fasten housing to mounting plate using four (4) tube screws.

Align round housing fastening holes with mounting plate fastening holes.

Screw #8x9/16"

The mounting plate will accommodate eight (8) different ceiling thicknesses.



15




### Install Natural Effect Lens

Top groove

Effect Lens

Carefully insert effect lens into housing and seat into top groove. Use care when installing to ensure seal on effect lens is not damaged.

Effect Lens






16

### Install Reflective Sleeve

Form reflective sleeve and insert into housing.

Once notches are aligned and in place, pull ends of sleeve out to connect and snap into place.

Use notches on reflective sleeve to align with housing fasteners and diffuser spring retainer.




For the most current Installation Instructions, please visit [www.solatube.com/instructions](http://www.solatube.com/instructions)

Solatube International, Inc. | 2210 Oak Ridge Way | Vista, CA 92081-8341 | [www.solatube.com](http://www.solatube.com) | T: 888.SOLATUBE



17

## Assemble Diffuser


Insert spring lock into diffuser notch





Press spring lock into notch



Install diffuser torsion spring over spring lock



Hold diffuser torsion spring firmly against diffuser and bed spring lock tabs





Completed diffuser



18

## Install Diffuser

Squeeze torsion springs and insert into spring locks.



Diffuser lens removed to show detail.



Push diffuser into housing until flush with ceiling.

For the most current Installation Instructions, please visit [www.solatube.com/instructions](http://www.solatube.com/instructions)


14

Solatube International, Inc. | 2210 Oak Ridge Way | Vista, CA 92081-8341 | [www.solatube.com](http://www.solatube.com) | T: 888.SOLATUBE

19


**Connect Tubing**  
Place tubing over housing .

Place tubing over housing until it rests on housing screws.



20

**Continue Building Tube Run**  
Refer to steps 3 through 9 to complete installation.




See page 16 and 17 for retrofit hard ceiling and suspended ceiling installations.

For the most current Installation Instructions, please visit [www.solatube.com/instructions](http://www.solatube.com/instructions)  
Solatube International, Inc. | 2210 Oak Ridge Way | Vista, CA 92081-8341 | [www.solatube.com](http://www.solatube.com) | T: 888.SOLATUBE

# Hard Ceiling Retrofit Construction Installation Instructions (ceiling in place)


21

Place Hard Ceiling Mounting Plate onto Ceiling  
Wood or metal framing




22

Fasten Mounting Plate to Framing



23

Bend Fastening Tabs Up







# Open Ceiling Installation Instructions

26

Determine Tube Configuration

NOTE: If utilizing Spectralight Softlight Tubing in open ceiling applications install at bottom of tube run (last extension tube) for best results.

Option 1:  
Single Extension Tube

Option 2:  
Additional length

Option 3:  
For pitched roofs

Option 4:  
For tall curb heights

27

Option 1: Assemble 24 in (610 mm) Extension Tube

Note: Spectralight Softlight Extension Tubes must be assembled to be parallel not tapered.

Remove Protective Liner

Assemble parallel tube for open ceiling configurations

Apply pressure to tape for proper bonding

28

Option 2: Assemble 48 in (1220 mm) Extension Tube

Note: Spectralight Softlight Extension Tubes must be assembled to be parallel not tapered.


Remove Protective Liner

Assemble parallel tube for open ceiling configurations

Apply pressure to tape for proper bonding

29


## Install Tube Ring and Diffuser



\* For installations where high levels of dirt or debris may be present it may be necessary to use foil tape to seal the diffuser to the tubing to prevent the excess debris from entering the tubing.

30

## Apply Tube Ring Seal and Install Tube Run




Return to step 8 to complete Open Ceiling instructions.

For DSA (Division of the State Architect) projects, it is necessary to add suspension wires to all open ceiling applications. See page 22 for instructions.

31

Now you can enjoy the benefits of your Solatube Daylighting System and the high performance, natural lighting it provides.



Please refer to the following section for a list of alternative flashings and accessories.




For the most current Installation Instructions, please visit [www.solatube.com/instructions](http://www.solatube.com/instructions)  
 Solatube International, Inc. | 2210 Oak Ridge Way | Vista, CA 92081-8341 | [www.solatube.com](http://www.solatube.com) | T: 888.SOLATUBE

# Curb Cap Flashing Insulation

## Installation Instructions Appendix

Parts List		Quantity
1	330 DS / 750 DS Curb Insulation	(4)



Additional Materials and Tools		Quantity
1	Roof Sealant	(1)
2	Foil Tape	(1)



# Self-Flashing Installation Instructions Appendix

Parts List	Quantity
1 Self-Flashing (4 in (100 mm), 8 in (200 mm), 11 in (280 mm))	(1)
2 Flashing Screws - #10 X 2 in (50 mm)	(21)


Additional Materials and Tools	Quantity
1 Roof Sealant	(3)
2 Straight Edge	(1)





3

Fasten Flashing to Roof.  
Apply Sealant and Spread Evenly Using Straight Edge.




## Requirements for DSA Projects Installation Instructions Appendix

**Note:** This section is intended to satisfy installations requirements for the DSA (Division of the State Architect).

### Suspended ceiling application

1

Set Transition Box  
For plastic polymeric or metal transition box.







# Turret Extension Installation Instructions Appendix

Parts List	Quantity
1 Turret Extension 12 in (300 mm), 24 in (600 mm), 36 in (900 mm), or 48 in (1200 m)	(1)
2 1/4 in (6 mm) screws	(4)


Additional Materials and Tools	Quantity
1 Roof Sealant	(1)



# 0-90 Degree Extension Tube Installation Instructions Appendix

Parts List	Quantity
1 Top Tube Angle Adaptor	(1)
2 Inner Angle Adaptor	(1)
3 Tube Screws - #8 X 9/16 in (14 mm)	(8)
4 Foil Tape - 2 in (51 mm) X 6 ft (2 m)	(2)

Additional Materials and Tools	Quantity
1 None	






For the most current Installation Instructions, please visit [www.solatube.com/instructions](http://www.solatube.com/instructions)  
Solatube International, Inc. | 2210 Oak Ridge Way | Vista, CA 92081-8341 | [www.solatube.com](http://www.solatube.com) | T: 888.SOLATUBE

# Dome Edge Protection Band Installation Instructions Appendix

Parts List		Quantity
1	Dome Edge Protection Band	(1)
2	Dome Edge Protection Band Tab	(3)

Additional Materials and Tools		Quantity
1	None	






For the most current Installation Instructions, please visit [www.solatube.com/instructions](http://www.solatube.com/instructions)

# Hard Ceiling Installation Instructions Appendix

**Note: This application is intended for the plastic polymeric transition box only.**

Parts List	Quantity
1 Transition Box	(1)
2 Drill Tip Screw 1 5/8 in (40 mm)	(4)

Additional Materials and Tools	Quantity
1 Wood Blocking	(2)
2 Shims	(4)



# Suspension Wire Kit Installation Instructions Appendix


## Plastic Polymeric Transition Box

Parts List		Quantity
1	12 Gauge Galvanized Wire 50 ft (15.25 m)	(1)
2	Anchor Bolts	(4)
3	Eye Bolt #8 1/8 in (25 mm) with Nut and (2) Washer	(4)

Additional Materials and Tools		Quantity
1	Drill Bit 1/8 in (3 mm)	(1)

1

Pre Drill Transition Box



Pre drill 4 holes in transition box with 1/8 in (25 mm) drill bit. \*


Transition Box

T-bar ceiling

\* Position holes to allow for natural effect lens.  
\* Bottom tube removed to show detail. Drill holes with bottom tube installed.

2

Install Eye Bolts



Washer

Eye Bolt

Nut


Washer

a

b

3

Attach Anchor Bolts and Install Suspension Wire



Suspension Wire

Attach anchor bolts to roof framing member and attach suspension wire.

a

b

Attach and twist wire end a minimum of 3 times.

# Suspension Wire Kit

## Installation Instructions Appendix

### Metal Transition Box with Softlight Technology

Parts List	Quantity
1 12 Gauge Galvanized Wire 50 ft (15.25 m)	(1)
2 Anchor Bolts	(4)
3 Eye Bolt #8 1/8 in (25 mm) with Nut and (2) Washer	(4)

Additional Materials and Tools	Quantity
1 Drill Bit 1/8 in (3 mm)	(1)

1

Pre Drill Transition Box

Pre drill 4 holes in transition box with 1/8 in (25 mm) drill bit. \*

Metal Transition Box

T-bar ceiling

\* Position holes to allow for natural effect lens.

\* Bottom tube removed to show detail. Drill holes with bottom tube installed.

2

Install Eye Bolts

Part of transition box has been cut-away to show detail.

Eye Bolt

Washer

Washer

Nut

3

Attach Anchor Bolts and Install Suspension Wire

Attach anchor bolts to roof framing member and attach suspension wire.

a

Attach and twist wire end a minimum of 3 times.

Suspension Wire


# Natural Effect Lens

## Installation Instructions Appendix

### Plastic Polymeric Transition Box

Parts List	Quantity
1 330 DS/750 DS Natural Effect Lens	(1)
2 Screw #6 X 3/8 in (10 mm)	(8)
3 Natural Effect Lens Tab	(8)

Additional Materials and Tools	Quantity
1 None	






# Natural Effect Lens

## Installation Instructions Appendix

### Metal Transition Box with Softlight Technology

Parts List	Quantity
1 330 DS/750 DS Natural Effect Lens	(1)

Additional Materials and Tools	Quantity
1 None	



# Thermal Insulation Panel (TIP) Installation Instructions Appendix





Parts List		Quantity
1	Thermal Insulation Panel (TIP)	(1)
2	Drill Tip Screw - #8 X 5/8 in (16 mm)	(4)
3	Tube Screws - #8 X 9/16 in (14 mm)	(6)
4	2 in (50 mm) Foil Tape - 6 ft (1.8 m)	(2)


Additional Materials and Tools		Quantity
1	None	

## Open Ceiling TIP Installation Instructions

For Applications with Insulation at Roof Level





**Note: For best thermal performance, install the Thermal Insulation Panel within the buildings insulation level.**





## Closed Ceiling TIP Installation Instructions

For Applications with Insulation at Ceiling Level with Plastic or Metal Transition Box




For the most current Installation Instructions, please visit [www.solatube.com/instructions](http://www.solatube.com/instructions)  
Solatube International, Inc. | 2210 Oak Ridge Way | Vista, CA 92081-8341 | [www.solatube.com](http://www.solatube.com) | T: 888.SOLATUBE

## Metal Transition Box Option


1a

Install Thermal Insulation Panel  
Place TIP onto Metal Transition box.




2a

Install Bottom Tube




3a

Apply Foil Tape




4a

Install Fastening Screws  
Secure each Fastening Strap to Bottom Tube and Transition Box.



5

Return to Main Set of Instructions to complete installation.





For the most current Installation Instructions, please visit [www.solatube.com/instructions](http://www.solatube.com/instructions)

# Closed Ceiling TIP with Daylight Dimmer Installation Instructions



For Applications with Insulation at Ceiling Level—Plastic or Metal Transition Box

- 1

Install Thermal Insulation Panel and Daylight Dimmer  
Place TIP onto transition box.




Place Daylight Dimmer onto TIP. Note: The Daylight Dimmer and the TIP share the same diameter. The Daylight Dimmer will rest on top edge of TIP.



- 2



Apply Foil Tape



- 3

Return to Main Set of Instructions to complete installation.

Secure Daylight Dimmer and Transition Box with Drill Tip Screws\*



Rotate Fastening Straps


\*Pre drill holes in Transition Box and Daylight Dimmer to prevent damage

For the most current Installation Instructions, please visit [www.solatube.com/instructions](http://www.solatube.com/instructions)  
Solatube International, Inc. | 2210 Oak Ridge Way | Vista, CA 92081-8341 | [www.solatube.com](http://www.solatube.com) | T: 888.SOLATUBE




4

Return to Main Set of Instructions to complete installation.




## Solatube Solamaster® Series Additional Accessories

Add more function by upgrading your Solatube Daylighting System with any of these great accessories.




### Daylight Dimmer

Because you don't need 100% of the light 100% of the time, the innovative Solatube Daylight Dimmer easily controls the amount of daylight entering a room with the convenience of a switch. Our patented variable butterfly baffle controls the light output.



### Flashing Insulator

This insulating material helps to reduce condensation in cold climates when the flashing is exposed to a humid interior space. The insulator is affixed to the flashing base and the top tube slips through the opening, which provides a seal between the interior and metal flashing.




### Open Ceiling Trim Ring

For use with the Solatube 330 DS and 750 DS Open Ceiling Configurations. The trim ring provides a finished appearance to the installation.



### Security Bar

This stainless steel bar insets into the flashing turret across the diameter of the opening. The bar is fastened using rivets and inhibits entry through the dome.



### Dome Security Kit

This kit consists of three rivets with nylon spacers, which replace dome screws. The dome security kit reduces the possibility of the dome being removed.

# Notes

# Notes



Solatube International, Inc.,  
2210 Oak Ridge Way, Vista CA 92081-8341  
Phone (800) 966-7652 • Fax (760) 599-5181  
**www.solatube.com**    Part No. 950160    v3.0